



| CAT. NO. | METAL | SCREW DRIVER |
|----------|-------|---|
| 1617.012 | SS | Hexagonal Screw Driver with Fibre Handle- Ø 3.5 mm Long For Pelvic |
| 1706.023 | SS | Screw Driver (Hexagonal) Ø 4.5mm for LL |
| 439.020 | SS | Hexagonal Screw Driver with Fibre Handle- Ø 2.7 mm |
| 439.035 | SS | Hexagonal Screw Driver with Fibre Handle- Ø 3.5 mm |
| 439.045 | SS | Hexagonal Screw Driver with Fibre Handle- Ø 4.5 mm |
| 439.050 | SS | SCREW DRIVER FOR PFNA II NECK SCREW |
| 439.119 | SS | Hexagonal Screw Driver with Fibre Handle- Ø 1.5 mm |
| 439.135 | SS | POLY AXIL Hexagonal Screw Driver with Fibre Handle- Ø 3.5 mm |
| 439.145 | SS | POLY AXIAL Hexagonal Screw Driver with Fibre Handle- Ø 4.5 mm |
| 439.151 | SS | SCREW DRIVER WITH T- HANDLE 2.5MM FOR DISPOSABLE SLEEVE 1.8/ 2.0MM |
| 439.152 | SS | SCREW DRIVER WITH T- HANDLE 3.5MM FOR DISPOSABLE SLEEVE 2.8 MM |
| 439.153 | SS | SCREW DRIVER 4.5MM FOR DISPOSABLE SLEEVE 4.3 MM |
| 439.160 | SS | UNIVERSAL SCREW DRIVER WITH T- HANDLE FOR PFN / PFNA II |
| 439.222 | SS | Star Screw driver 1.5/2.0 (T6) |
| 439.224 | SS | Star Screw driver 2.4/2.7 (T8) |
| 439.226 | SS | Star Screw driver 3.5 (T15) |
| 439.228 | SS | Star Screw driver 4.5 (T25) |
| 439.245 | SS | Large Hexagonal Screw Driver with Holding Sleeve- Ø 4.5mm |
| 439.350 | SS | Small Hexagonal Screw Driver with Holding Sleeve- Ø 3.5 mm |
| 439.501 | SS | Screw driver (hexagonal) 4.5mm for pfna ii antirotationscrew size 4.5mm |
| 439.502 | SS | IMPACTOR SCREWS DRIVER CANNULATED FOR PFNA II |
| 439.515 | SS | Hexagonal Screw Driver with Q.C Shaft- Ø 1.5 mm |
| 439.520 | SS | Hexagonal Screw Driver with Q.C Shaft- Ø 2.0 mm |
| 439.535 | SS | Hexagonal Screw Driver with Q.C Shaft- Ø 3.5 mm |
| 439.545 | SS | Hexagonal Screw Driver with Q.C Shaft- Ø 4.5 mm |
| 439.612 | SS | Spare Sleeve For Maxillofacial Screw Driver |
| 439.613 | SS | MAXILLOFACIAL SCREW DRIVER WITH SCREW HOLDING SLEEVE CROSS SLOTT with Q.C Shaft |
| 439.614 | SS | MAXILLOFACIAL SCREW DRIVER |

Specification

- Screw Drivers are available in Stainless steel.

Indication for use

- Screw Driver use to fix screw in the fixator plate like reconstruction, plate pelvic plate etc.

